



Check function of the floor socket together with the flush bolt !

Service instruction:

- * test function 1-2 times per year**
- * lubricate
- * and if necessary/possible adjust movable parts

** High frequency doors or demanding environments may require more frequent service.

contents:
floor socket
screws

art.no: type 1 : 471014417

v 1.0

MA17HZ	A	2018-03-20
--------	---	------------